



LATHEM TIME



Tip: Setting the Time DWA Series

The following setting instructions refer to the display of the DWA, DWA18-1 and 4000DWA Series.

"Old Style" Keypad

EDAY 0	SAT 7	ON
SUN 1	8	OFF
MON 2	9	HD
TUE 3	AM	CLR
WED 4	PM	MEM CLR
THU 5	WK	CLK
FRI 6	CKT	*

To set the time on an "Old Style" keypad:

- If you have a 4000DWA Series, wait until you here the clock "click", make a sample registration and note the time
- Set the Time of Day by pressing
  1. Current Day of Week
  2. **WK**
  3. **AM** or **PM**
  4. Hour and Minutes (set the minutes one-minute ahead of the clock time)
  5. Wait until the clock "clicks" and press **CLK**

Example: To set the time to Monday, 9:30AM press:

MON 2	WK	AM	9	3	0	CLK
----------	----	----	---	---	---	-----

Note: A colon in the upper left area of display indicates PM

"New Style" Keypad

SET TIME	SET DAY	PGM SIGNALS
12/24 HR DISPLAY	SIGNAL OFF	SIGNAL LENGTH
RESTART	CLEAR SIGNAL	NEXT SIGNAL
SUN	MON	TUE
WED	THU	FRI
SAT	REV	FWD
MANUAL SIGNAL	TEST BATT	RUN

To set the time on a "New Style" keypad:

- If you have a 4000DWA Series, wait until you here the clock "click", make a sample registration and note the time
- Set the Day of Week by pressing
  1. **SET DAY**
  2. Current Day of Week
  3. **RUN**
- Set the Time of Day by pressing
  1. **SET TIME**
  2. Press **FWD** or **REV** to set the display one-minute ahead of the clock time
  3. Wait until the clock "clicks" and press **RUN**

Example: To set the Day of Week to Monday press:

SET DAY	MON	RUN
---------	-----	-----

Example: To set the Time of Day to 9:30AM press:

SET TIME	FWD	RUN
----------	-----	-----

Note: A colon in the upper left area of display indicates PM